

RB398S PARTS LIST			
MODEL	PART NUMBER	PART CODE	DESCRIPTION
RB398S	1	BB40112	BOLT 3X6
RB398S	2	BB86701	TORX BOLT 3X5
RB398S	3	RB70404	ARM B UNIT
RB398S	4	RB11999	WIRE GUIDE B
RB398S	5	RB12000	CUTTER
RB398S	6	JJ10109	E-RING 2
RB398S	7	RB12090	CUTTER LEVER B
RB398S	8	JJ10514	E-RING 3 CF
RB398S	9	RB12005	CUTTER LEVER A
RB398S	10	FF51647	HOLLOW PIN 1647
RB398S	11	RB12710	SHAFT
RB398S	12	RB12004	CONNECTING ROD
RB398S	13	RB12780	PIN
RB398S	14	RB11998	WIRE GUIDE A
RB398S	15	RB12121	FIXED CUTTER
RB398S	16	RB70493	CUTTER PLATE UNIT
RB398S	17	RB12781	PLATE
RB398S	18	RB81304	ARM A UNIT
RB398S	19	RB11997	LEAF SPRING
RB398S	20	AA25113	PAN-HEAD SCREW 2X4
RB398S	21	RB70741	ARM ASSY
RB398S	22	KK33413	APRING 3413
RB398S	23	BB40839	SCREW 4X16
RB398S	24	RB12007	PIPE SPONGE
RB398S	26	JJ10101	E-RING 4
RB398S	27	RB81136	PIPE ASSY
RB398S	28	RB70565	CURL GUIDE UNIT
RB398S	29	RB12010	CURL GUIDE COVER
RB398S	30	KK33365	TORSION SPRING
RB398S	31	RB11708	STOPPER SHAFT
RB398S	32	RB70567	CURL GUIDE ASSY
RB398S	33	RB11816	HOOK
RB398S	34	RB81113	WS PIN 2.5X10
RB398S	35	RB12014	KEY
RB398S	36	RB12017	SLEEVE A
RB398S	37	RB12279	SLEEVE GUIDE
RB398S	38	RB70675	TIP AXIS B
RB398S	39	FF31599	PARALELL PIN 1599
RB398S	40	KK23730	COMP SPRING 3730
RB398S	41	RB12708	TIP AXIS A
RB398S	42	RB12015	SLEEVE B
RB398S	43	RB12789	CUTTER RING
RB398S	44	RB12091	CUTTER RING GUIDE
RB398S	45	JJ21011	C-RING 14
RB398S	46	RB81314	TIP AXIS ASSY
RB398S	47	RB12020	SPRING COLLAR
RB398S	48	KK29026	COMP SPRING 9026
RB398S	49	RB12019	BUMPER
RB398S	51	JJ21603	C-RING 20
RB398S	52	RB10338	INTERNAL GEAR
RB398S	53	RB12783	RING
RB398S	54	RB70745	PLANET CAGE UNIT
RB398S	55	FF31589	PIN 1589
RB398S	56	RB10341	PLANET GEAR
RB398S	57	RB10484	GEAR PRESS WHEEL
RB398S	58	RB70736	SUN GEAR UNIT
RB398S	59	RB70734	TWISTING MOTOR

RB398S	60	EE31131	WASHER 1-3
RB398S	61	FF51817	HOLLOW PIN 1817
RB398S	62	BB40810	BOLT 3X16
RB398S	63	RB70710	SENSOR CIRCUIT BOARD F UNIT
RB398S	64	RB81347	REEL GUIDE ASSY
RB398S	65	AA09501	SCREW 3X6
RB398S	66	FF51710	HOLLOW PIN 1710
RB398S	67	BB41706	BOLT 4X10
RB398S	68	FF31563	PIN 1563
RB398S	69	KK34089	SPRING 4089
RB398S	70	RB70719	RATCHET COVER ASSY
RB398S	71	BB40720	BOLT 3X12
RB398S	72	RB12791	SPECIFICATION LABEL
RB398S	73	RB70705	MOTOR COVER ASSY
RB398S	74	FF41871	STEP PIN 1871
RB398S	75	KK34067	TORSION SPRING 4067
RB398S	76	EE39609	PLAIN RUBBER WASHER
RB398S	77	BB40714	BOLT 3X50
RB398S	78	RB12031	JOINT
RB398S	79	AA21419	SCREW 3X8 CF
RB398S	80	RB81305	REEL HOLDER ASSY
RB398S	82	RB12038	REEL STOPPER SPRING
RB398S	83	EE39184	WASHER 3.1X11.8X1
RB398S	84	RB12035	REEL STOPPER
RB398S	85	FF21240	PIN 2.5X6
RB398S	86	RB12036	STOPPER PLATE
RB398S	87	RB70427	REEL STOPPER ASSY
RB398S	88	RB70770	REEL MAGAZINER ASSY
RB398S	89	RB12772	PLATE B
RB398S	90	BB41707	BOLT 4X16
RB398S	91	EE11103	SPRING WASHER 2-4
RB398S	92	EE39825	WASHER 4.5X7.4X0.8
RB398S	93	KK24175	COMP SPRING 4175
RB398S	94	JJ10113	E-RING 2.5
RB398S	95	RB10359	FEEDING GEAR B2
RB398S	96	RB10362	RELEASE LEVER
RB398S	97	FF41809	STEP PIN 1809
RB398S	98	RB12852	HOLLOW PIN
RB398S	99	EE32104	WASHER 2-3
RB398S	100	RB10357	FEEDING GEAR B1
RB398S	102	RB12766	WIRE GUIDE C
RB398S	103	CC41104	HEX NUT 1-3
RB398S	104	RB12761	PARTITION PLATE
RB398S	105	RB12765	PARTITION SPONGE
RB398S	106	EE31133	WASHER
RB398S	107	RB70509	FEEDING GEAR A ASSY
RB398S	108	RB70729	FEEDING MOTOR ASSY
RB398S	109	RB81312	FEEDING ASSY
RB398S	110	RB10368	JAW A
RB398S	111	KK33249	TORSION SPRING 3249
RB398S	112	RB10370	JAW BASE
RB398S	113	FF41822	STEP PIN 1822
RB398S	114	RB10369	JAW B
RB398S	115	RB70495	JAW BASE ASSY
RB398S	116	RB12769	ROTARY PIN
RB398S	117	RB81308	SOLENOID ASSY
RB398S	118	FF41876	STEP PIN 1876
RB398S	120	FF52119	HOLLOW PIN 2119
RB398S	121	RB12029	ROTARY PLOATE

RB398S	122	FF21620	PIN 2X12
RB398S	123	RB81306	BRAKE ASSY
RB398S	124	BB40712	BOLT 4X8
RB398S	125	RB12770	REEL PRESS
RB398S	126	KK33373	SPRING 3373
RB398S	127	AA22522	SCREW 3X8
RB398S	128	ZS00034	MAIN SWITCH UNIT
RB398S	129	RB12796	LABEL TORQUE DIAL
RB398S	130	RB12814	HARNESS COVER
RB398S	131	RB81309	SWITCH BASE ASSY
RB398S	132	RB12054	STEP PIN
RB398S	133	RB12053	RELEASE STOPPER
RB398S	134	RB12055	STOPPER BASE
RB398S	135	RB12056	SPONGE F
RB398S	136	RB81139	STOPPER BASE ASSY
RB398S	137	KK29133	COMPRESSION SPRING 9133
RB398S	138	BB40710	BOLT 3X8
RB398S	140	BB40709	BOLT 3X16
RB398S	141	RB12771	PLATE A
RB398S	142	CC42512	HEX NUT 1A M4 CF
RB398S	143	RB12521	WARNING LABEL
RB398S	144	FF51714	HOLLOW PIN 1714
RB398S	145	RB12745	REEL PROTECTOR
RB398S	146	BB41503	BOLT 3X8
RB398S	147	RB11979	COVER L
RB398S	148	RB70708	FRAME L ASSY
RB398S	149	RB11987	WINDOW
RB398S	150	RB12826	CONNECTOR BASE
RB398S	151	RB12827	CONNECTOR COVER
RB398S	152	AA05572	SCREW 3X8
RB398S	153	RB12080	TRIGGER
RB398S	154	KK23656	COMPRESSION SPRING 3656
RB398S	155	RB12101	TRIGGER LOCK LEVER
RB398S	156	RB81349	SWITCH HARNESS UNIT
RB398S	159	RB12744	SWITCH BLOCK
RB398S	160	RB81341	MAIN CIRCUIT BOARD UNIT
RB398S	161	KK23604	COMPRESSION SPRING 3604
RB398S	162	RB12813	FRONT HARNESS COVER
RB398S	163	RB70697	ELECTRODE UNIT
RB398S	165	RB11981	COVER R
RB398S	166	RB12689	WARNING LABEL
RB398S	167	RB11985	USAGE LEVEL
RB398S	169	RB12742	398S LABEL
RB398S	171	RB70706	FRAME R ASSY
RB398S	173	RB81184	BELT HOOK ASSY
RB398S	174	RB12752	LED COVER
RB398S	176	RB12661	BRAND PLATE